RefriLink

REFRILINK TECHNICAL WHITE PAPER SERIES

Engineering the Low-GWP Refrigerant Transition

A system-level approach to reducing refrigerant climate impact without compromising safety or performance

DOCUMENT	REVISION	ISSUE	AUDIENCE
WP-02	1.0	September 2026	Global B2B / Technical



TECHNICAL PURPOSE

Practical engineering guidance for refrigerant selection, quality control, handling, logistics and application support.

EXECUTIVE SUMMARY

Executive Summary

Lower-GWP refrigerants are changing equipment platforms, service practices and project specifications across the HVAC&R industry. Transition planning works best when treated as a system-engineering program rather than a simple fluid substitution. The refrigerant, compressor, heat exchangers, controls, safety measures, charging method, service tools and technician training must be evaluated as one integrated design.

Key Takeaways

01
Lower GWP can require new equipment architecture and safety controls.

02
Direct emissions and energy-related emissions should be considered together.

03
A phased transition plan reduces supply, training and compliance risk.

1. What Changes in a Low-GWP Transition?

Area	What may change	Why it matters
Equipment design	Pressure class, compressor, heat exchanger, expansion device	Thermophysical properties differ between refrigerants
Safety	Flammability controls, charge limits, detection and ventilation	Many lower-GWP options are A2L or A3
Service	Recovery machine, leak detector, vacuum/charging process, labeling	Tools and work practices must match the refrigerant and safety class
Controls	Setpoints, superheat/subcooling logic, defrost, pressure limits	Operating envelope and blend behavior may differ
Supply chain	Cylinder types, availability, transport and documentation	New refrigerants may have different packaging and logistics profiles

2. Transition Pathways by Application

Application	Illustrative lower-GWP pathways	Key engineering focus
Residential / light commercial AC	R32; selected A2L blends; R290 in suitable product categories	Charge control, indoor safety, installer training, compressor envelope
Commercial HVAC	A2L blends and application-specific alternatives	Building code, machinery-room strategy, leak detection, service procedures
Supermarket refrigeration	R744 architectures; selected lower-GWP blends	System architecture, high pressure for R744, heat recovery, service capability
Industrial refrigeration	R717 and R744 where appropriate	Site safety, machinery room, relief systems, operator competence
Automotive AC	R1234yf and other OEM-approved systems	OEM platform compatibility, service equipment, recovery and contamination control
Transport refrigeration	Application-specific low-GWP fluids and R744 solutions	Ambient range, vibration, service network and energy consumption

ILLUSTRATIVE ONLY
The pathways above are not interchangeable recommendations. Actual refrigerant options depend on the equipment design, manufacturer approval and local regulations.

TRANSITION ENGINEERING

3. Direct vs. Indirect Climate Impact

A lower refrigerant GWP reduces the potential impact of leaked refrigerant, but total climate performance also depends on system energy use. A transition that materially reduces efficiency can offset some direct-emissions gains. For this reason, project teams should compare refrigerant charge, expected leakage, refrigerant GWP, annual energy consumption, grid carbon intensity and end-of-life recovery using a consistent lifecycle method.

Input	Why it belongs in the comparison
Installed charge	Sets the potential direct-emission inventory
Annual leakage assumption	Converts charge into expected operating losses
End-of-life recovery rate	Affects terminal direct emissions
Seasonal energy consumption	Usually dominates indirect emissions over long operating periods
Operating climate	Changes pressure ratio, capacity and efficiency
Maintenance quality	Influences leak rate and sustained energy performance

4. A2L Readiness

- Use equipment explicitly designed and certified for the selected A2L refrigerant.
- Verify charge limits, occupied-space requirements and leak-management provisions for the application.
- Apply tools and instruments rated for the refrigerant and flammability class.
- Control ignition sources and maintain appropriate ventilation during installation and service.
- Train service teams on cylinder identification, recovery, evacuation, charging and emergency procedures.
- Keep refrigerant identification and service labels legible throughout the product life.

5. Program Governance

1. Create an approved-refrigerant list by product family and market.
2. Build an equipment qualification matrix covering compressors, valves, heat exchangers, controls and safety components.
3. Define new service tools, training and field procedures before product launch.
4. Qualify refrigerant suppliers for purity, traceability and continuity of supply.
5. Pilot in representative climates and duty cycles before full rollout.
6. Track field leakage, energy performance, service incidents and refrigerant quality trends.

IMPLEMENTATION

6. Transition Readiness Scorecard

Gate	Ready when...
Engineering	The refrigerant is approved for the full operating envelope and all safety controls are defined.
Manufacturing	Filling, leak testing, labeling and contamination-control procedures are updated.
Service	Technicians, tools, recovery equipment and procedures are available in launch markets.
Supply	Qualified sources, packaging formats, inventory strategy and logistics routes are in place.
Compliance	Market-specific documentation and conformity requirements are mapped and owned.
Field support	Technical escalation, incident response and quality feedback loops are operating.

7. Procurement and Inventory Strategy

- Avoid mixing transition refrigerants in shared cylinders, recovery equipment or storage where cross-contamination is possible.
- Use clear product coding and physical segregation for similar cylinder colors or form factors.
- Set minimum remaining shelf/inspection life for cylinders and packaging where applicable.
- Maintain batch traceability from receipt through filling and dispatch.
- Plan safety stock using lead time, market demand and regulatory phase-down/phase-out timelines relevant to the target region.

Conclusion

A successful low-GWP transition is a coordinated engineering and operational change. The refrigerant is only one element; equipment, safety, service, quality and supply-chain capability must move together.

Reference Frameworks

- ISO 817 and/or ASHRAE Standard 34 for refrigerant designation and safety classification.
- Equipment manufacturer engineering manuals and approved refrigerant lists.
- Applicable regional refrigerant-management and product-safety requirements.
- Current safety data sheet for each refrigerant handled or supplied.

Important Notice

TECHNICAL GUIDANCE ONLY

This white paper is general engineering guidance. Refrigerant selection, charging, storage, transport and servicing must follow the equipment manufacturer instructions, the applicable safety data sheet, cylinder/pressure-vessel requirements and all local laws, codes and dangerous-goods rules. Product suitability must be verified for the specific system and jurisdiction.